

## 9000 ALARM UP TO 95

### TRANSPORT (SERVICE) MODE :

(To get back to regular mode no matter what mode you get into, just turn the key to unlock 3 times within 2 sec.)

Open the trunk or the hood.

Open any door except the driver's door.

Turn key in driver's door to unlock and hold for 10 sec..

Release key and wait 5 sec.. LED should flash once.

Turn key to unlock twice in 5 sec.. LED should flash once every 4 sec. (After 5 minutes it goes out).

Shut door and trunk.

### ADJUSTMENT OF SENSITIVITY :

After you are in the TRANSPORT MODE as listed above.

Turn driver's door lock to unlock and hold until siren blares and lights flash.

LED should flash once every 2 sec.. Wait 10 sec. later and the LED will flash twice per sec.

To decrease sensitivity, turn the key in driver's door to lock and release.

Wait 2 sec.. This moves the setting one step.

You can go 13 steps from the default setting and then the siren will chirp, telling you you are at the limit.

To increase sensitivity, follow same procedure except turn to unlock instead of lock.

Repeat the adjustment(turn to lock, hold, release), until you can pull the driver's mirror to a position just before it locks and letting it snap back in place without triggering the alarm.

If the alarm sounds when you snap the mirror, it will quickly stop and you can continue to adjust sensitivity by turning the key to lock until the siren doesn't sound with the snap.

When you get the sensitivity so that the mirror snap doesn't set off the alarm, turn the key to unlock twice within 2 sec.. The LED should flash

once every 4 sec.. Then turn key to unlock three times within 2 sec.. Open door and close, then lock door.

Alarm should arm with your programmed sensitivity and will hold it even if the battery is disconnected.

NOTE: Turning the key to unlock three times in 2 sec. when not exiting transport mode will set the sensitivity back to the default setting. like disconnecting the battery on older cars. Just do the three times to unlock to exit transport. After you are out of transport, doing it will wipe out your programming, and reinstall the default factory settings.

### QUICK SUMMARY:

1. Turn Key in drivers door to **UNLOCK 3X** rapidly
2. Open left rear door and trunk
3. Turn Key to **UNLOCK and Hold** for 10 - 15 seconds
4. Release Key to Neutral
5. As soon as the Led flashes ONCE ...
6. Turn Key to **UNLOCK 2X** rapidly
7. Close trunk and left rear door

8. Turn Key to **UNLOCK and HOLD IT** till the alarm sounds and the lights flash.

9. Wait for Led to flash very fast

10. Turn Key to **LOCK** and release

11. Wait at least 2 seconds

12. Do it 4 - 5 times.

13. Turn Key **UNLOCK 2X** rapidly

14. Wait for Led to flash Once every 4 seconds

15. Turn Key **UNLOCK 3X** rapidly